

Base Case

Pit Expansion

Shaft

Offset Footwall Zone
(Above 1065L)

Roby Footwall Zone

Offset Fault

1065 Mine Level

Offset Hangingwall Zone

Offset Footwall Zone

Phase 2

Open

Open

